

STO905

DISHWASHER, BUILT-IN INTEGRATED,
12 PLACE SETTINGS, HORIZONTAL 90 CM,
ENERGY RATING A+

EAN13: 8017709184810

12 place settings

Number of programs: 6 + 4 quick programs

Double orbital wash system

Buffer memory

Display: Delayed start display

Delay timer option up to 9 hours, with automatic soak

Visual indicator: salt and rinse aid

Varied distribution 1/2 load option FlexiZone

Stainless Steel basket with grey components

Lower basket with completely foldable racks and glass holder

12 place setting sliding cutlery basket

Basket with anti-drop system

Lower basket with anti-drop insert

Single hot/cold water max 60°C alimentation - energy save
up to 35%

Annual water consumption: 3220 l/year

Annual energy consumption: 289 kWh/year

Noise level: 43 dB (A) RE 1 pW

Current: 10 A

Frequency: 50 Hz

Voltage: 220-240 V















Functions
















Plus and Options

-
- A+:**
 Energy efficiency class A+ helps to save up to 10% energy compared to class A. Maximum performance with minimum consumption is guaranteed.
-
- 13 plate settings:**
 The symbols show the number of plate settings of the dishwasher.
-
- ORBITAL WASH SYSTEM:**
 Orbital wash system distributes water evenly throughout the 60cm dishwasher cavity, directing water with precision to ensure an excellent wash.
-
- DELAY TIMER:**
 The delay timer can postpone the start of the program by up to 24 hours.
-
- FlexiZone:**
 The ½ load flexizone allows you to wash a reduced load saving energy, water and time and there are no restrictions on where the items are placed.
-
- Quick Time:**
 The Quick Time option can reduce the length of the wash cycle up to 55%.
-
- Total acquastop:**
 Most models of Smeg dishwashers are equipped with Acquastop Totale, which allows to avoid flooding as a result of water leakage. The system consists of a float sensor, disposed under the inner chamber of a dishwasher, which blocks water supply inside the appliance in case of water leakage into the lower tray. An additional electromagnetic valve on the water inlet hose also automatically blocks water supply if detecting water leakage in the hose. For Laundry: Total acquastop, the product is built with 3 levels of anti-flood devices to ensure protection against water leakage. For Laundry: Total acquastop, the product is built with 3 levels of anti-flood devices to ensure protection against water leakage.
-
- AQUATEST:**
 Aquatest measures the clarity of the water during an auto program, and automatically ensures the minimum consumption of water and energy.
-
- Rompi-goccia:**
 Some models of dishwashers are equipped with special polymer nozzles Rompi-Goccia, that improve the process of drying.
-
- FLEXITABS:**
 Flexitabs adjusts the wash cycle to give the best possible results regardless of the type of detergent used.
-
- WATERSAVE:**
 System WaterSave ensures the best washing results with minimal water consumption depending on the model of dishwasher.
-
- Noise Level:**
 Excellent insulation and special devices keep noise to a minimum.
-
- Installation in column:**
 Installation in column
-

Programs

-  **Soak programme:**
The soak programme provides a rinse to prevent dirt from drying.
-  **CRYSTAL:**
The crystal cycle is a particular programme designed especially for delicate dishes with light dirt.
-  **Eco:**
Eco, this economic wash programme uses a low amount of water and energy in order to provide the most environmentally friendly cleaning option.
-  **Super:**
The super programme is suitable for removing stubborn dirt.
-  **Auto 45°- 65°:**
The auto programme regulates the length of a cycle depending on the need for a pre-wash and the number of rinses required.
-  **Eco:**
Eco, this economic wash programme uses a low amount of water and energy in order to provide the most environmentally friendly cleaning option.
-  **RAPID 27 MINS:**
The rapid 27 mins quick program takes just 27 minutes to wash a load.
-  **Normal Quick:**
Program Normal Quick is suitable for quick washing of mixed dishes, for everyday use.
-  **Delicate Quick:**
Program Delicate Quick is suitable for quick washing of delicate dishes.
-  **STRONG & FAST:**
This special programme takes less than 1 hour to eliminate the most stubborn dirt and dried on residues.



attenzione: dimensioni riferite ad installazione con pannelli di spessore 20 mm.
Per pannelli di spessore diverso, consultare il manuale di installazione completo.