

STA4503

DISHWASHER, BUILT IN FULLY INTEGRATED,
45 CM, 10 PLACE SETTINGS,
ENERGY RATING A

EAN13: 8017709177041

10 place settings

Number of programs: 5

Swing wash system

Buffer memory

Delay timer option 3-6-9 hours, with automatic
soak

Visual indicator: salt and rinse aid

Grey baskets

Height adjustable upper basket on three
horizontal levels

Upper basket with central fixed racks

Lower basket with central fixed racks

10 place setting sliding cutlery basket

Lower basket with anti-drop insert

Single hot/cold water max 60°C alimentation -
energy save up to 35%

Annual water consumption: 3080 l/year


Annual energy consumption: 266 kWh/year

Noise level: 47 dB (A) RE 1 pW

Current: 10 A

Frequency: 50 Hz

Voltage: 220-240 V



Functions



Plus and Options

Programs



Plus and Options



A:
Product drying performance, measured from A+++ to D / G depending on the product family



10 plate settings:
The symbols show the number of plate settings of the dishwasher.



Swing Wash System:
The Swing Wash system ensures optimum water distribution throughout 45cm dishwasher tanks to deliver excellent wash results.



DELAY TIMER:
The delay timer can postpone the start of the program by up to 24 hours.

Total acquastop:

Most models of Smeg dishwashers are equipped with Acquastop Totale, which allows to avoid flooding as a result of water leakage. The system consists of a float sensor, disposed under the inner chamber of a dishwasher, which blocks water supply inside the appliance in case of water leakage into the lower tray. An additional electromagnetic valve on the water inlet hose also automatically blocks water supply if detecting water leakage in the hose. For Laundry: Total acquastop, the product is built with 3 levels of anti-flood devices to ensure protection against water leakage. For Laundry: Total acquastop, the product is built with 3 levels of anti-flood devices to ensure protection against water leakage.



FLEXITABS:
Flexitabs adjusts the wash cycle to give the best possible results regardless of the type of detergent used.



WATERSAVE:
System WaterSave ensures the best washing results with minimal water consumption depending on the model of dishwasher.



Noise Level:
Excellent insulation and special devices keep noise to a minimum.

Programs



Soak programme:
The soak programme provides a rinse to prevent dirt from drying.



CRYSTAL:
The crystal cycle is a particular programme designed especially for delicate dishes with light dirt.



Eco:
Eco, this economic wash programme uses a low amount of water and energy in order to provide the most environmentally friendly cleaning option.



1/2 load:
This program is designed for washing dishes not heavily soiled with partial load of the dishwasher.



Super:
The super programme is suitable for removing stubborn dirt.

